

PAT.

EVO UITORION

Tang-thru screwdriver with built-in impact driven screw removal function

✓ "Stripped screws"



✓ "Rusted screws"



✓ "Stuck screws"



Only IMPACTA can do!

into Ro

Even if the screw head is stripped,

"IMPACTA"
can remove it
instantly!!

MPACIA With a hammer to loosen the stucks are will

Cam rotation mechanism

Our proprietary Tang-Thru nut incorporates cam rotation mechanism, which turns the driving tip counter-clockwise by 12 degrees when the handle is hit with a hammer. IMPACTA leverages impact acceleration to remove

stuck screws.



No.980

Sp-proof heme 199

Non-Slip

Non-slip surface secures a firm grip even when your hands are covered with oil.

When used with oil-covered hands, tightening torque becomes 26% higher with "MEGADORA IMPACTA" than with other normalscrewdrivers.

Non-slip surface makesthe difference.

Please consult I



No. S-980/S-983 MEGADORA IMPACTA

Patented





Magnetized (Eco-friendly

- •Tang-Thru nut with cam rotation mechanism.
- •Fully hardened chrome vanadium steel shank.
- Black point tip is processed with high precision.

	EDP No.	Size		mm	Mm	- - - -			- -	EAN(JAN) 4907587
Ī	S-980									
	125960	⊕2	×100	PH	2	6.4	100	215	32	107404
	125961	⊕3	×150	PH	3	8 0	150	275	34	107411
	S-983									
	125956	⊕ 2	×100	PZ	2	6.4	100	215	32	107954
	125958	⊕ 3	×150	PZ	3	8.0	150	275	34	107978

Do not use this product to remove screws on materials that could be damaged or distorted, such as aluminum and thin sheet metal.



Choose a right screwdriver for your screw. The wrong size screwdriver may damage the screw hole.

VESSEL CO., INC.

17-25, Fukae-Kita 2-chome, Higashinari-ku, Osaka 537-0001 JAPAN Tel: +81(0)6 6976 7778 Fax: +81(0)6 6972 9441

VESSEL EUROPE

6, avenue du 1er Mai, ZAE Les Glaises, 91120 Palaiseau FRANCE Tel : +33(0)1 69 19 17 42 Fax : +33(0)1 69 19 42 20

E-mail: export@vessel.co.jp URL: http://www.vessel.co.jp/english/

Due to product improvement, the specifications shown in this brochure are subject to change without notice.

Distributed by

Printed in Japan 14022821.005